



ASSEMBLY AND OPERATING INSTRUCTIONS



CONTENTS

I About The Product










1-1	Product Information	2
1-2	Parts List	6

III Appendix

3-1	User's Manual	16
3-2	After-sales Service	17
3-3	Disclaimer	17
3-4	Custom Canopy	18
3-5	More Products	19

II Installation

2-1	Before Assembly	7
2-2	Safety Tips	7
2-3	Setting Up	8
2-4	Taking Down	11
2-5	Installation Instructions For Wheels	14
2-6	Instructions For The Awning	15



Product Information

Product Name	POP UP CANOPY
Color	White
Top Material	Polyester
Bracket Material	Alloy Steel
Specifications	10 ft x 10 ft / 8 ft x 8 ft 10 ft x 15 ft / 8 ft x 12 ft 10 ft x 20 ft / 8 ft x 16 ft
Applicable Season	Four Seasons
Applicable Venue	Party, Commercial Events, Sports Activities, Camping

CT03



CT04



CT05

P3

P3-1 Door wall
P3-2 Side wall



CT06

P3

P3-1 Door wall
P3-2 Side wall



CT07

P3

P3-1 Door wall
P3-6 Church window



CT08

P3

P3-1 Door wall
P3-2 Side wall
P3-3 Awning



W



CT10

P3

P3-1 Door wall
P3-2 Side wall



CT11

P3

P3-1 Door wall
P3-2 Side wall



CT30

P3

P3-4 Mesh door
P3-5 Mesh wall



CT34

P3

P3-4 Mesh door
P3-5 Mesh wall






PARTS LIST

Part#		Qty	Part#		Qty
P1		1	P5		4/6
P2		1	P6	 or 	4
P4		1	P7		4
			P8		1

FRAME PART NUMBER

A Dome cap	E Joint bolt / nut / washer & bolt cap	I Lower peak pole bracket	M Peak pole outer
B Foot pad	F 2 Way outer leg bracket	J Outer leg w/ velcro	N Peak pole inner
C Inner leg	G 2 Way outer leg slider bracket	K Inner leg height adjuster	Q 3 Way outer leg bracket
D Joint bolt / nut / washer	H Upper peak pole bracket	L Truss bar	R 3 Way outer leg slider bracket



Tips: Any requests for replacing or purchasing the replacement parts, please contact us by email and tell us the Part Number you need.

BEFORE ASSEMBLY



2 PERSON



10-20 MIN ASSEMBLY




HAMMER

SAFETY TIPS

1. Please read this manual thoroughly and carefully before assembling and using the item, follow all instructions and keep the manual for future reference.
2. Proper use of the item includes observing the safety instructions in this manual and the information on the proper use of the item outdoors and for private purposes.
3. If any parts are missing, broken, damaged or worn, do not use this product until repairs have been made and/or factory replacement parts have been installed.
4. Do not use this item in a way not recommended by the manufacturer, as any damage caused will not be covered by the warranty.
5. Non-compliance with the general and safety instructions in this manual may result in personal injury and/or serious damage to the item. We shall not be liable for any such loss.
6. Place the item on a stable and level surface.
7. Do not use or store this item close to open flames or flammable/combustible chemicals.
8. Be careful not to pinch hands or appendages during assembly.
9. Do not attempt to assemble this item under the following circumstances: Drunk/Inclement weather/Lack of tools or parts/Without assistance

SETTING UP



► Step 1

Remove frame from box and stand upright in the center of the desired setup location.
Gently pull the outer legs until the frame is partially expanded.

Step 2 ◀

Attach the canopy top to each frame corner with velcro straps.
Place the Dome cap (Part A) into the pocket and pull the drawstring tight.



SETTING UP



► Step 3

Lift the frame into position by expanding the truss bars until frame is fully expanded. Lift the slide bracket to the highest position. Attach the velcro straps on the truss bar.

Tips: Please note that the **red peak tensioner** is used to adjust the issue of the top becoming loose after prolonged use. When hearing crack, it means it comes the top. New products do not require adjustment.

Step 4 ◀

Adjust the frame legs to your desired height.



SETTING UP

Step 5 ◀

Attach the side walls with velcro straps and zippers according to your own requests.

Tips: This step is required for products with side walls.



▶ Step 6

Use sandbags, ropes and stakes for fixation.

Tips: Filled the sandbags with sand, rock, gravel, snow, dirt or other contents. Use hammer to anchor the stakes if necessary.

TAKING DOWN



► Step 1

Remove stakes, ropes and sand bags securing the canopy to the ground.

Step 2 ◀
Carefully Unzip the zippers and take down velcro straps on each side to remove the side walls.

Tips: when taking this step, please don't put too much strength to avoid tearing.





TAKING DOWN

Step 3 ◀

Position the legs to its lowest position by adjusting the slider bracket.
Carefully pick down the velcro straps on the truss bar.

Tips: When removing the top, the Velcro straps must be removed first!
Failure to remove the velcro straps will cause the top and frame to wear out!




▶ Step 4

Slightly lift the frame and push slowly until about ½ way closed.
Carefully take down the velcro straps on each frame corner
and put away the canopy top.
Release the pocket and remove the bowler hat (Part A) from the pocket.

Tips: when taking this step, please don't put too much strength to avoid tearing.

TAKING DOWN



► Step 5

Push the frame into fully closed.

Step 6 ◀

Store the frame back in the roller bag.



SETTING UP INSTALLATION INSTRUCTIONS FOR WHEELS



Step 1: Big wheel x2
Screw*2
Screw nut*2



Step 2: Attach the screw and
nut to the wheel, **retaining out
2MM gap.**



Step 3: Turn the locking screw
counterclockwise.



Step 4: Tighten the nut
counterclockwise
until it is no longer loose



Step 5: It is done.



INSTRUCTIONS FOR THE AWNING (ONLY FOR CT08)



Step 1: Connect the awning pole together.



Step 2: Insert and pass the awning fabric.



Step 3: Install the support pole on the tent frame.



Step 4: Finish the set up and enjoy canopy shade.



USER'S MANUAL

- It is recommended that you use the ropes and stakes to secure the canopy.
- This product is not intended to withstand periods of extreme/high wind or storm.
- Check the connection of the frame regularly to ensure that it is firm and stable.
- If the frame structures have water stains, please clean up with a soft cloth in time to prevent rust.
- When not in use, please remain closed and stored away to avoid potential damage.

AFTER-SALES SERVICE

About returns and refunds

Items shipped from Amazon.com, including Amazon Warehouse, can be returned within 30 days of delivery. You can visit the Amazon's Customer Service homepage to get help:

<https://www.amazon.com/returns>

Items shipped from our shop, also can be returned within 30 days of delivery. If the reason for return is a result of an error or a damage on product, we will provide a pre - paid shipping label. If the reason for return is personal dislike or improper size, you need afford the extra returning fee.

Pictures may be required for some returns to ensure an item is not damaged prior to its return.

Product Support


The warranty of our product is **ONE YEAR** after-sale protection for frame, **SIX MONTHS** after-sale protection for fabrics and accessories (**NOT INCLUDE** damage caused by improper personal use and bad weather). If you need help with using your product or if it doesn't work correctly, please feel free to contact us through Amazon. Pictures or Videos may be required to ensure which part is damaged or doesn't work.

DISCLAIMER

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

CUSTOM CANOPY

The Pop Up Canopies can be customized to fit your needs. Add a custom top , walls or banner to make a bold statement. We offer digital dye sublimation and silk screened printing and up to 100% full print coverage in vivid images and precision clarity without compromise. We also offer Custom Table Cover, Feather Flag, Teardrop Flag.



CUSTOM WORKS



Pop Up Canopies





Table Cover



Teardrop Flag



Side Walls

MORE PRODUCTS



TA55



TB51



SK01



TD42

MORE PRODUCTS



AJ01



CT07



AJ18



PD01

MORE PRODUCTS



UB02



UB03



UB04



UB09

Always be creative.

